




2017

PRODUCT
CATALOG




Spare parts for trucks
and heavy machinery


truckskv.com



Air filters




Article	Nomenclature	h, mm	D Out, mm	D In, mm
A-1325SKV	Air filter 17801-3380SKV / A-1325 SKV	437	232	122
A-1330SKV	Air filter 17801-3390SKV / A-1330 SKV	428/420	110	102
28113-4F000SKV	Air filter 28113-4F000 / PAA-049 / YUMI-056 / EAF00088M SKV	114 / 134	145 / 250	83 / 188
28130-44000SKV	Air filter 28130-44000 / PAA-013 / YUMI-021 SKV	279/287	133	85 / 18.5
28130-5A500SKV	Air filter 28130-5A500 / PAA-069 / YUMI-111 / A-28650 / D4DD/ GA / County/HD78 SKV	305	235	128/22
28130-5H002SKV	Air filter 28130-5H002 / 28130-5H001 / MAF023 / PAA-032 / YUMI-042 County/HD72 SKV	288	198	132
A800SKV	Air filter 2996155/MF800/A800 Iveco SKV	469.5 / 482.2	327.0	215.9 / 10.3
A-1004SKV	Air filter A-1004 / A-1177 / 17801-78030/78020 HINO300 E-3 N04C/J05D/S05 SKV	249	235	128
A-1009SKV	Air filter A-1009 / A-3370 / 17801-78040 HINO300 E-3 N04C/W04D SKV	160,5	219	109
A-6014S SKV	Air filter A-6014S / A578SET / 1-14215-203-0 + 1-14215-217-0 CX#/CY#/CV#/EX# SKV	452/447	280 / 174	174 / 132
A0040942404SKV	Air filter A0040942404 SKV Mercedes	338.1	403.2 / 519.9	221.5
A0040943504SKV	Air filter A0040943504 / RS5358 / 1485592 SKV Mercedes	528.6	267.5	167.5
A26031SKV	Air filter A26031 / 17801-78110 / A13570 SKV	216	237	132
A274SKV	Air filter A274 / 1-14215-108-0 / 1-14215-197-0 / 1-14215-067-0 SKV	331/ 343	232	147 / 23
A282SKV	Air filter A282 / A-1335M / 17801-3450 / S1780-13450 / 1-14215-102-0 E13CTL HINO700 SKV	360 / 374	281	173
A282IN SKV	Air filter A282IN / A-1336M / 17801-3460 SKV	358	173	128
A3002SKV	Air filter A3002 / ME294400/ME292262/ME017242 SKV	218 / 240	180	93
A3003SKV	Air filter A3003 / ME017246 / A1088 SKV	265 / 288	230	119
A3015SKV	Air filter A3015 / MD620563 / 8-94135-886-0 ELF150/250, MMC L200/Pajero SKV	189	155,5	86 / 12
A364SKV	Air filter A364 / A-1019 / 8-94430-250-0 NPR75/NQR71/NLR85/NQR90 E-4 SKV	330 / 343	264 / 221	136 / 23
A370SKV	Air filter A370 / ME073160/ME073821 SKV	403/406	236	132
A371SKV	Air filter A371 / ME121023/ME294850/ME290841 SKV	370 / 362	280	150
A519SKV	Air filter A519 / 8-97030-325-0 / 16546-89TA4 SKV	235	154	80
A5562S SKV	Air filter A5562S / 6I2507 / A-5561 + A-5560 SKV	381.5 / 393.5	317.6	209



Air filters


Article	Nomenclature	h, mm	D Out, mm	D In, mm
A579SKV	Air filter A579 / A-6020M/8-97062-294-0/5-87610-020-0 4HK1/4J1 NQR71/75/NPR75/NLR/NMR55,85 SKV	291 / 279	236	132
A581SKV	Air filter A581 / 8-98071-423-0 / A24581 ISUZU 6HK1/FVR34 SKV	392	281	148
A581INSKV	Air filter A581IN / 8-98071-424-0 / A-6037 ISUZU 6HK1/FVR34 SKV	376,5	141	109
A617SKV	Air filter A617 / 620 / 17801-2830 HINO, HINO 500, 700 SKV	358 / 370	274	152 / 22,5
A622SKV	Air filter A622 / A-1324 / S1780-13360 / 17801-E0010 HINO 500 SKV	320 / 343	215	120




Oil filters

Article	Nomenclature	h, mm	D Out, mm	D In, mm	D thread
C110SKV	Oil filter C110 / 90915-10001 / 15601-33021 SKV	75	65		3/4"-16UNF
C115SKV	Oil filter C115 / 90915-30002 / 90915-03006 SKV	120	100		M24x1.5
C223SKV	Oil filter C223 / 15201-Z9013 / ME074235 SKV	220	125		M36x1.5
C305SKV	Oil filter C305 / ME014838 / 26320-41402 MMC Canter/HYUNDAI CHORUS/HD250,350 SKV	10	90		M18x1.5
C313SKV	Oil filter C313 / C-1012 / C-5816 / 26311-45001 / 26311-45010 / ME013307 SKV	150	102		M26x1.5
C315SKV	Oil filter C315 / ME088532 / ME228898 SKV	179	108		M26x1.5
C409ASKV	Oil filter C409A / SL02-23-802 / TFY0-14-302 SKV	135	102		1 "x12 UNF
C411SKV	Oil filter C411 / SL50-14-V61 SKV	125	90		M20x1.5
C503SKV	Oil filter C503 / 5-13211-018-0 / 8-94167-399-0 / ME997803 SKV	125	102		M20x1.5
C506SKV	Oil filter C506 / 8-94340-259-1 ELF250/350/450, MAZDA BONGO/FORD, N-Vanette SKV	80	102		M20x1.5
C513SKV	Oil filter C513 / 8-94463-713-1 ISUZU ELF250/350/450 4BE1/2,BC2,BD1,BG1	100	80		M22x1.5

Oil filters




Article	Nomenclature	h, mm	D Out, mm	D In, mm	D thread
C525SKV	Oil filter C525 / C-1513 / 1-87610-064-0 / 8-94391-049-0 / 8-94396-375-4 SKV	210	120		1-1/2"x12UNF
C526SKV	Oil filter C526/518 /C-1515 / C-1534 / 5-87610-031-0 / C-1562 / 8-97148-270-0 / 15209-89TA1 SKV	120	120		1-1/2"x12UNF
C5701SKV	Oil filter C5701 / 600-211-1231 / 600-211-1291 SKV	286	118		1-1/2"x12UNF
C602SKV	Oil filter C602 /C-1303/S1560-71733 / 5-86506-949-0 SKV	200	110		1-1/2"x16UNF
C605SKV	Oil filter C605 /C-1316/S1560-72190/72330/15209-Z5001 HINO 500 FD8/GD8/GH8 J08 E-3/4 SKV	210	120		1-1/2"x16UNF
C606SKV	Oil filter C606 /15607-2200 / 15607-1670 / 15209-Z5002 SKV	150	120		1-1/2"x16UNF
C607SKV	Oil filter C607 / 15607-2210 / 15613-89105 HINO Dutro/Ranger/T-Dyna/Coaster S05D/C,J05/07C,N04C	150	102		1"x16 UNF
C608SKV	Oil filter C608 /C-1318/C-1328/15613-89106/15613-E0080 HINO300 E-3, 4 /T-DYNA N04C/W04D SKV	150	102		1"x12UNF
O258SKV	Oil filter O258 / OE258J / O-1805 / 15274-90226 SKV	235	130	16	
O259SKV	Oil filter O259 / OE259J / O-1808 / LF3384 / 15274-99029 SKV	160	128	63 / 16	
O358SKV	Oil filter O358 / ME034605 / ME034611 SKV	188	110	32 / 20	
O359SKV	Oil filter O359/OE359SET/MC755406 / ME054238 / ME064355 / 31230-53015 / O-1012 SKV	140,5 / 160 / 300,5	128 / 130	58 / 15,5	
O579SKV	Oil filter O579 / O568 / O-1308 / O609 / 15607-2261 / 15607-1100/1-13240-233/MB-J302 SKV	180	104	15 / 49	
O581SKV	Oil filter O581 / O-1522 / O1530 / 1-13240-207-0 /1-13240-241-0 CX#/CY#/CV#/EX# E-2/3/4/5 SKV	183	130	17	
O584SKV	Oil filter O584 / EO-1501 /8-98018-858-0/1K04-23-802/15208-89TOA NLR/NMR 55,85 4JJ1 E-4/5 SKV	151 / 157	65.5 / 35	17	
O620SKV	Oil filter O620 / 15607-1580 / 15607-2160 SKV	249	122	17	
O621SKV	Oil filter O621 / OE621 /S1560-71531 / 15607-1950 / O-1310 SKV	219	122	17	
O625SKV	Oil filter O625 / O-1321 / 15607-2150 / S1560-72281 HINO 700 E13C-T SKV	206 / 226	140	17	
O630SKV	Oil filter O630 / S1560-72281 / 15607-2280 SKV	206	140	17	
O631SKV	Oil filter O631 / S1560-72370 HINO / HINO700 E13C-T SKV	179	104,5	48	
O632SKV	Oil filter O632 / S1560-72380 HINO / HINO700 E13C-T SKV	208	141		




Hydraulic filters

Article	Nomenclature	h, mm	Ø Out, mm	Ø In, mm
H-5504SKV	Hydraulic filter H-5504 SKV	234	101	59
H-5510SKV	Hydraulic filter H-5510 SKV	177.5	130	84.4



Drier filters


Article	Nomenclature	h, mm	Ø Out, mm	Ø In, mm	Thread
A0004293795SKV	Drier filter A0004293795 / 4324100202 / 1-85576-365-0 Mercedes SKV	167.5	139.7	-	M39 x 1.5



Fuel separator assemblies

Article	Nomenclature
R90T SKV	Fuel separator assy YYZC-F033 R90T SKV

Fuel filters




Article	Nomenclature	h, mm	Ø Out, mm	Ø In, mm	Thread
23304-EV023SKV	Fuel filter 23304-EV023/22/21 HINO 300 XZU7## N04C 13~ E-4 SKV	80	102	78/12	1"x14UNF
8981398300SKV	Fuel filter 8-98139-830-0 SKV	160	108,0		
EF13070SKV	Fuel filter EF13070 / 23304-78090 HINO300/DYNA WU/,XZU710,720,730 N04CTSKV	146 / 112	84	28	
F1306SKV	Fuel filter F-1306 / ME300647/23355-78020 HINO-300/DYNA BU3##, WU30#, 34#, XZU3# N04CT E-3 SKV	99	95		
F195SKV	Fuel filter F195 / EF1112 / 23390-78221 / 23390-78220 SKV	69 / 92,5	78/84		
F337SKV	Fuel filter F337 / EF-1003/ME222135 MMC FUSO Canter E-3 SKV	85	94	26	
F507SKV	Fuel filter F507 / F-1503 / 1-87810-976-0 / 1-87810-207-1 CX#/CY#/CV#/EX# E-2/3/4/5 SKV	166 / 160	101	14,5	
F513SKV	Fuel filter F513 / EF-1509/8-98037-011-0 4JJ1/4HK1/6HK1 NQR90/NLR85/FSR90/NPR75/FVR34 E-4/5 SKV	96 / 114,5	96		
F606SKV	Fuel filter F606 / F-1304 / S2340-11090 / 23401-1390 SKV	104	104	49/15	
F610SKV	Fuel filter F610 / EF-1301 / 23401-1690 / S2340-11690 E13C HINO 700 SKV	132	90	19,3	
F611SKV	Fuel filter F611 / EF-1802 / S2340-11682 / 23304-EV030 HINO 500 E3/4 SKV	110 / 116	90	19	
FC158SKV	Fuel filter FC158 / 23303-64010 / 23390-30150 / R2N5-13-ZA5 SKV	137	90		3/4"x16UNF
FC174SKV	Fuel filter FC174 /TF01-13-ZA5 /23401-1520/23304-78020 HINO Dutro/Ranger, Toyoace/Dyna, M-Titan	100	80		M20x1.5
FC208A SKV	Fuel filter FC208A / 16403-Z7000 / 16403-89TA1 / 16403-09W00 SKV	88	80		3/4"x16UNF
FC226SKV	Fuel filter FC226 / 5-86102-498-0 / 16400-58N00 SKV	138,5	87		3/4 "x16 UNF
FC232SKV	Fuel filter FC232 / 16403-99003 / 16403-99007 SKV	175	93		1 "x14 UNF
FC28190SKV	Fuel filter FC28190/ 31945-45700 SKV	142	80		M10x1.5 / M16x1.5
FC331SKV	Fuel filter FC331 / ME150631 / ME162902 SKV	201	108		1-1 / 8 "x16 UNF
FC332SKV	Fuel filter FC332 / FC-1009 / ME132525 / MB-CX513 FUSO Canter 4M50/51 SKV	140,5	87		M20x1.5/M2 2X1.5
FC607SKV	Fuel filter FC607 / 8-94394-079-0 / 23401-1332 / S2340-11510 SKV	100	80		3/4"x16UNF
FC609SKV	Fuel filter FC609 / 23401-1372 / S23401-1650 SKV	125	102		1 "x14 UNF
R90T SKV	Fuel filter R90T /S234011840/8-98139-830-0 NPR/NMR/NLR, HINO500/700, NPR75/NQR90 08~ E-4 SKV	160	108		M23x1.75
SF1307SKV	Fuel filter SF-1307 / S2340-11730 / 16403-Z900J HINO 500 GD8/FD8 J08E E-3 SKV	189 / 193	95	27	
SFC530410SKV	Fuel filter SFC-5304-10/ 31945-52161/31945-45900/ 31945-7L002/ A0004771602/ 504272431 SKV	158	108	17	1"x14
SFC550430SKV	Fuel filter SFC-5504-30 / 8-98081-862-0 / MB-R120P SKV	217	108	17	1"x14



Spare parts for trucks
and heavy machinery




Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm
14-90-1700	Leaf spring 14-90-1700 SKV	14	90	1400
10-60-1200H	Leaf spring 10-60-1200H SKV	10	60	1200
10-60-1500	Leaf spring 10-60-1500 (without central hole) SKV	10	60	1500
11-60-1300H	Leaf spring 11-60-1300H SKV	11	60	1300
11-60-700H	Leaf spring 11-60-700H SKV	11	60	700
11-60-900H	Leaf spring 11-60-900H SKV	11	60	900
11-70-1100H	Leaf spring 11-70-1100H SKV	11	70	1100
11-70-1300H	Leaf spring 11-70-1300H SKV	11	70	1300
11-70-1500H	Leaf spring 11-70-1500H SKV	11	70	1500
11-70-1700H	Leaf spring 11-70-1700H SKV	11	70	1700
11-70-700H	Leaf spring 11-70-700H SKV	11	70	700
11-70-900H	Leaf spring 11-70-900H SKV	11	70	900
13-60-1100H	Leaf spring 13-60-1100H SKV	13	60	1100
13-60-1300H	Leaf spring 13-60-1300H SKV	13	60	1300
13-60-1500H	Leaf spring 13-60-1500H SKV	13	60	1500
13-60-700H	Leaf spring 13-60-700H SKV	13	60	700
13-60-900H	Leaf spring 13-60-900H SKV	13	60	900
13-70-1100H	Leaf spring 13-70-1100H SKV	13	70	1100
13-70-1300H	Leaf spring 13-70-1300H SKV	13	70	1300
13-70-1500H	Leaf spring 13-70-1500H SKV	13	70	1500
13-70-700H	Leaf spring 13-70-700H SKV	13	70	700
13-70-900H	Leaf spring 13-70-900H SKV	13	70	900
13-80-1100H	Leaf spring 13-80-1100H SKV	13	80	1100
13-80-1300H	Leaf spring 13-80-1300H SKV	13	80	1300
13-80-1500H	Leaf spring 13-80-1500H SKV	13	80	1500
13-80-900H	Leaf spring 13-80-900H SKV	13	80	900
14-70-1100H	Leaf spring 14-70-1100H SKV	14	70	1100
14-70-1300H	Leaf spring 14-70-1300H SKV	14	70	1300
14-70-1500H	Leaf spring 14-70-1500H SKV	14	70	1500
14-70-9-1300H	Leaf spring 14-70-9-1300H SKV	9/14	70	1300

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm
16-80-1100H	Leaf spring 16-80-1100H SKV	16	80	1100
16-80-1300H	Leaf spring 16-80-1300H SKV	16	80	1300
16-80-1500H	Leaf spring 16-80-1500H SKV	16	80	1500
16-80-550H	Leaf spring 16-80-550H SKV	16	80	550
16-80-910H	Leaf spring 16-80-910H with clamps SKV	16	80	910
16-90-1300H	Leaf spring 16-90-1300H SKV	16	90	1300
16-90-1500H	Leaf spring 16-90-1500H SKV	16	90	1500
16-90-88-1600H	Leaf spring 16-90-88-1600H SKV	16	88/99	1600
20-70-10-1100H	Leaf spring 20-70-10-1100H SKV	20	70	1100
20-90-1000H	Leaf spring 20-90-1000H SKV	20	90	1000
20-90-12-1500H	Leaf spring 20-90-12-1500H HINO (3-rd parabolic leaf) SKV	12/20	90	1500
20-90-1300H	Leaf spring 20-90-1300H SKV	20	90	1300
20-90-88-1600H	Leaf spring 20-90-88-1600H SKV	20	88/90	1600
60-1300-16-11H	Leaf spring 60-1300-16-11H SKV	60	11/16	1300
70-1300-16-11H	Leaf spring 70-1300-16-11H SKV	70	11/16	1300
8-70-1200H	Leaf spring 8-70-1200H SKV	8	70	1200
8-70-1500	Leaf spring 8-70-1500 (without central hole) SKV	8	70	1500
8-70-900H	Leaf spring 8-70-900H SKV	8	70	900
80-18-10-1100H	Leaf spring 80-18-10-1100H SKV	80	10/18	1100
80-18-10-1500H	Leaf spring 80-18-10-1500H SKV	80	10/18	1500
9-70-1300H	Leaf spring 9-70-1300H SKV	9	70	1300
9-70-900H	Leaf spring 9-70-900H SKV	9	70	900
14-80-1100H	Leaf spring 14-80-1100H SKV	14	80	1100
14-80-1300H	Leaf spring 14-80-1300H SKV	14	80	1300
14-80-1500H	Leaf spring 14-80-1500H SKV	14	80	1500
14-80-900H	Leaf spring 14-80-900H SKV	14	80	900
14-90-1500H	Leaf spring 14-90-1500H SKV	14	90	1500
16-70-1300H	Leaf spring 16-70-1300H SKV	16	70	1300

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
A091-2902101-01	Leaf spring A091-2902101-01 Bogdan main front (silentblocks) SKV	10	70	1290	81*42*16 / 42*40*16
A091-2902102-01	Leaf spring A091-2902102-01 Bogdan undermain front SKV	10	70	1290	
A091-2912101-01	Leaf spring A091-2912101-01 Bogdan main rear (silentblocks) 10*70 SKV	10	70	1340	81*42*18 / 42*40*16
A091-2912102-01	Leaf spring A091-2912102-01 10*70 Bogdan undermain rear SKV	10	70	1320	
54111-5A301	Leaf spring 54111-5A301 11*70 HYUNDAI County 04~ main front (2 bushings + 2 silentblocks) SKV	11	70	1205	43*40*36 / 60*19*46
54111-5K500	Leaf spring 54111-5K500 11*70 HD45/65/72/78/75 04~ main front (2 silentblocks + 2 bushings) SKV	11	70	1210	43*40*36 / 42*44*16
54112-5A301	Leaf spring 54112-5A301 11*70 HYUNDAI County 04~ undermain front SKV	11	70	1215	
54112-5K500	Leaf spring 54112-5K500 10*70 HD45/HD65/HD72/HD78/MIGHTY/HD35/75 04~ undermain front SKV	10	70	1220	
54113-5K500	Leaf spring 54113-5K500 10*70 HD45/HD65/HD72/HD78/MIGHTY/HD35/75 04~ 3-rd leaf front SKV	10	70	955	
55100-4B700-1	Leaf spring 55100-4B700-1 8x60 HYUNDAI H100 Porter 96~ main rear (1 bushing 28*34*58) SKV	8	60	1200	28*34*58
55100-4B700-2	Leaf spring 55100-4B700-2 7x60 HYUNDAI H100 Porter 96~ undermain rear SKV	7	60	1220	
55111-5A300	Leaf spring 55111-5A300 11*70 HYUNDAI County 04~ main rear (2 bushings + 2 silentblocks) SKV	11	70	1360	43*40*36 / 60*19*46
55111-5K500	Leaf spring 55111-5K500 10*70 HD45/65/72/78/MIGHTY 04~ main rear (2 bushings 28*34*68) SKV	10	70	1250	28*34*68
55112-5A300	Leaf spring 55112-5A300 11*70 HYUNDAI County 04~ undermain rear SKV	11	70	1375	
55112-5K500	Leaf spring 55112-5K500 11*70 HD45/65/72/78/MIGHTY 04~ undermain rear SKV	11	70	1265	
55113-5K500	Leaf spring 55113-5K500 11*70 HD45/65/72/78/MIGHTY 04~ 3-rd leaf rear SKV	13	70	955	
1-51131-962-0	Leaf spring 1-51131-962-0 14*80 Isuzu CYZ51 LHD main front (2 bushings 32*42*78 + oil seals) SKV	14	80	1600	32*42*78
1-51132-962-0	Leaf spring 1-51132-962-0 14*80 Isuzu 10t CYZ51 LHD undermain front SKV	14	80	1600	
1-51411-118-0	Leaf spring 1-51411-118-0 10*70 Isuzu 5T Frear/FSR/FRD 97~ main rear (bushing 25*30*68) L=1380 SKV	10	70	1380	25*30*68
1-51412-118-0	Leaf spring 1-51412-118-0 10*70 Isuzu 5T Frear/FSR/FRD/FRD-S/Frear-S 97~ undermain rear SKV	10	70	1380	
48101-37692	Leaf spring 48101-37692 DYNA/TOYOACE BU4#/#/XZU4#/# 99- main front 124cm SKV	15/13/9	70	1245	83*40*16
48101-3B550	Leaf spring 48101-3B550 9*70 DYNA/TOYOACE 84-99 main front 1146mm (silentblocks) SKV	9	70	1146	83*40*16

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
48101-4300	Leaf spring 48101-4300SKV HINO FW2 main Front SKV	20/14	90	1300	
48112-37690	Leaf spring 48112-37690 15*70 DYNA/TOYOACE BU4##/XZU4## 99- undermain front SKV	15/10/9	70	1245	
48112-3B550	Leaf spring 48112-3B550 DYNA/TOYOACE BU7#/8#/9# 87-95 undermain front SKV	8	70	1140	
48201-3B060	Leaf spring 48201-3B060 DYNA/TOYOACE 84-99 main rear 120 cm (silentblocks) SKV	12	70	1206	76*40*16
482013V140A	Leaf spring 48201-3V140-A DYNA/TOYOACE BU4##/XZU4## 99- main rear (2 bushings 25-31-68) SKV	11	70	1292	25*31*68
48201-E0120	Leaf spring 48201-E0120 18x70 HINO 500 main rear (2 bushings 30-36-68) SKV	18/13	70	1290	30*36*68
48202-3B060	Leaf spring 48202-3B060 12*70 DYNA/TOYOACE 84-99 undermain rear SKV	12	70	1216	
48212-E0110	Leaf spring 48212-E0110 18x70 HINO 500 undermain rear SKV	18/11	70	1306	
8-97084-637-0	Leaf spring 8-97084-637-0 / 70*11 Isuzu NPR main rear (silentblocks D=18 D=16) SKV	11	70	1244	81*42*18 / 42*40*16
8-97084-637-1	Leaf spring 8-97084-637-1 / 8-97084-638-0 70*13 Isuzu NQR main rear (silentblocks D=18 D=16) L=1	11	70	1244	81*42*18 / 42*40*16
8-97084-637-2	Leaf spring 8-97084-637-2 / 8-97084-639-0 70*13 Isuzu NQR 1375mm undermain rear SKV	13	70	1375/ 1244	
8-97084-638-0	Leaf spring 8-97084-638-0 / 8-97084-639-0 70*12 Isuzu ELF NPR undermain rear L=1254mm SKV	12	70	1254	
8-97130-493-0	Leaf spring 8-97130-493-0 Isuzu ELF NPR/NQR 93 main rear 70*12 (silentblock D=18/D=16)L=1352 SKV	12	70	1360	81*42*18 / 42*40*16
8-97130-494-0	Leaf spring 8-97130-494-0 Isuzu ELF NPR/NQR 93~ undermain rear 70*13 L=1362mm SKV	13	70	1362	
8-97133-074-0	Leaf spring 8-97133-074-0 Isuzu ELF NPR/NQR 93~ main front 70*10 (silentblocks) SKV	10	70	1300	81*42*16 / 42*40*16
8-97133-075-0	Leaf spring 8-97133-075-0 Isuzu ELF NPR/NQR 93~ undermain front 70*10 L=1300mm SKV	10	70	1300	
8-98042-335-0	Leaf spring 8-98042-335-0 9*60 Isuzu NLR/NMR55/85 08~ main front (bushings.40*43*30) SKV	9	60	1140	40*43*30
8-98042-336-0	Leaf spring 8-98042-336-0 9*60 Isuzu NLR/NMR55/85 08~ undermain front SKV	9	60	1140	
8-98044-390-0	Leaf spring 8-98044-390-0 11*70 Isuzu NLR/NMR55/85 08~ main rear (silentblocks42*16, bushings.43*40) SKV	11	70	1200	42*16
8-98044-391-0	Leaf spring 8-98044-391-0 11*70 Isuzu NLR/NMR55/85 08~ undermain rear (with clamps) SKV	11	70	1200	

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
8-98073-686-0	Leaf spring 8-98073-686-0 Isuzu FVR34 main front (bushings 32*38*78) 21*80 SKV	21/14	80	1600	32*38*78
8-98073-687-0	Leaf spring 8-98073-687-0 Isuzu FVR34 undermain front 24*80 SKV	24/14	80	1610	
8-98073-688-0	Leaf spring 8-98073-688-0 Isuzu FVR34 3-rd leaf with clamp front 24*80 SKV	24/14	80	1600	
8-98161-621-0	Leaf spring 8-98161-621-0 35/18*90/88 Isuzu CYZ52 1-st leaf (main) rear SKV	18/35	90	1600	
8-98161-622-0	Leaf spring 8-98161-622-0 35/18*90 Isuzu CYZ52 2-nd leaf (undermain) rear SKV	18/35	90	1510	
8-98161-623-0	Leaf spring 8-98161-623-0 35/18*90 Isuzu CYZ52 3-rd leaf rear SKV	18/35	90	1600	
8-98241-220-0	Leaf spring 8-98241-220-0 70*11 Isuzu ELF NPR75 main rear (silentblocks D=18 D=16) SKV	11	70	1300	81*42*18 / 42*40*16
8-98241-221-0	Leaf spring 8-98241-221-0 70*12 Isuzu ELF NPR75 undermain rear SKV	12	70	1300	
48101-37590	Leaf spring DSF51 / 48101-37590 11*70 Hino Dutro/Dyna/Isuzu 5t main front 25*31 SKV	11	70	1200	25*31*68
48112-37590	Leaf spring DSF52 / 48112-37590 13*70 Hino Dutro / Dyna / Isuzu 5t undermain front SKV	13	70	1210	
48101-4270	Leaf spring HSF112 / 48101-4270 14*90 Hino 10t main front (2 bushings 30*42) SKV	14	90	1500	30*42*88
48101-4271-30	Leaf spring HSF118 / 48101-4271 Hino 10t 90*14 main front (2 bushings 30*38) SKV	14	90	1500	30*38*88
48112-3251	Leaf spring HSF12 / 48112-3251 14*90 Hino 10t undermain front SKV	14	90	1512	
48101-3V420	Leaf spring HSF31 / 48101-3V420 10*70 Hino 300 main front (2 bushings 25-31-68) SKV	10	70	1240	25*31*68
48112-3V640	Leaf spring HSF32 / 48112-3V640 10*70 Hino 300 undermain front SKV	10	70	1255	
48101-4080	Leaf spring HSF51 / 48101-4080 (11x60x70) Hino 5t main front (2 bushings 25-31-68) SKV	11	64/70	1303	25*31*68
48101-4080	Leaf spring HSF51 / 48101-4080 11*70 Hino 5t main front (2 bushings 25-31-68) SKV	11	70	1303	25*31*68
48112-4741	Leaf spring HSF52 / 48112-4741 (11x60x70) Hino 5t undermain front SKV	11	64/70	1313	
48112-4741	Leaf spring HSF52 / 48112-4741 11*70 Hino 5t undermain front SKV	11	70	1313	
48201-4490	Leaf spring HSR11 / 48201-4490 Hino 10t main rear (bushing 38-50-88) SKV	16	90	1640	38*50*88
48212-6990	Leaf spring HSR12 / 48212-6990 16*90 Hino 10t undermain rear SKV	16	90	1598	

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
48201-3V630	Leaf spring HSR31 / 48201-3V630 11x70 Hino 300 main rear (2 bushings 25-31-68) SKV	11	70	1306	25*31*68
48212-3V630	Leaf spring HSR32 / 48212-3V630 11x70 Hino 300 undermain rear SKV	11	70	1317	
48201-3060	Leaf spring HSR51 / 48201-3060 11x70 Hino 5t main rear (bushing 30-36-68) SKV	11	70	1440	30*36*68
48201-3060	Leaf spring HSR51 / 48201-3060-13 13x70 Hino 5t main rear (bushing 30-36-68) SKV	13	70	1440	30*36*68
48212-4810	Leaf spring HSR52 / 48212-4810 13x70 Hino 5t undermain rear SKV	13	70	1453	
8-97084-827-0	Leaf spring ISF01 8-97084-827-0 Isuzu Elf NPR main front (silenblocks) SKV	12/10	70	1140	81*42*16 / 42*40*16
8-97084-828-0	Leaf spring ISF02 8-97084-828-0 70*13 Isuzu Elf NPR undermain front SKV	13/9	70	1140	
1-51111-504-1	Leaf spring ISF11 / 1-51111-504-1 Isuzu 10t main front (2 bushings 32-38-78) SKV	14	80	1457	32*38*78
1-51111-504-1A	Leaf spring ISF11A / 1-51111-504-1A Isuzu 10t main 25*80 tapered thickness front (2 bushings 32-42-78) SKV	25/12	80	1600	32*42*78
1-51112-505-1	Leaf spring ISF12 / 1-51112-505-1 Isuzu 10t undermain front SKV	15	80	1460	
1-51112-505-1A	Leaf spring ISF12A / 1-51112-505-1A Isuzu 10t undermain 25*80 tapered thickness front SKV	25/12	80	1610	
1-51161-085-0	Leaf spring ISF51 / 1-51161-085-0 13*70 Isuzu 5t main front (2 bushings 25-30-68) SKV	13	70	1355	25*30*68
1-51132-085-0	Leaf spring ISF52 / 1-51132-085-0 Isuzu 5t undermain front SKV	13	70	1365	
1-51411-123-0	Leaf spring ISR51 / 1-51411-123-0 Isuzu 5t main rear (bushing 25-30-68) L=1430 SKV	13	70	1430	25*30*68
1-51412-123-0	Leaf spring ISR52 / 1-51412-123-0 Isuzu 5t undermain rear SKV	13	70	1433	
MB391277	Leaf spring MB391277 Canter 2t undermain 15*70 tapered thickness rear SKV	15/8	70	1260	
MB391393	Leaf spring MB391393 Canter 2t main 15*70 tapered thickness rear (2 bushings 28-34-68) SKV	15/8	70	1250	28*34*68
MC091214-V	Leaf spring MC091214-V 15x70 Canter 3-rd leaf tapered thickness SKV	15/8	70	1250	
MC114662	Leaf spring MC114662 Canter 2t main 11*70*1250 rear (bushings) SKV	11	70	1250	43*40*36
MC114663	Leaf spring MC114663 Canter 2t undermain 11*70*1260 rear SKV	11	70	1260	
MC120891	Leaf spring MC120891 Canter main front (bushings) SKV	10	70	1206	43*40*36
MC120892	Leaf spring MC120892 MPF2 №02 10*70 Canter undermain front SKV	10	70	1216	

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
MK305770	Leaf spring MK305770 11*70 FUSO CANTER main rear (2 bushings 28-34-68) SKV	11	70	1302	28*34*68
MK305772	Leaf spring MK305772 14*70 FUSO CANTER undermain rear SKV	14	70	1312	
MK305773	Leaf spring MK305773 14*70 FUSO CANTER 3-rd leaf with clamps rear SKV	14	70	870	
MK470961	Leaf spring MK470961 11*70 FUSO CANTER main front (bushings 43-40-36) SKV	11	70	1208	43*40*36
MK470962	Leaf spring MK470962 11*70 FUSO CANTER undermain front SKV	11	70	1154	
MK470963	Leaf spring MK470963 11*70 FUSO CANTER 3-rd leaf with clamps front SKV	11	70	830	
MK311007	Leaf spring MSF118 / MK311007 14*90 Fuso 10t main front (2 bushings 32-38-88) SKV	14	90	1502	32*38*88
MK091087	Leaf spring MSF51 / MC091087 Fuso 5t/HD120 main 11*70 front (2 bushings 28-34-68) SKV	11	70	1302	28*34*68
MC091087-V	Leaf spring MSF51V / MC091087-V Fuso 5t main tapered thickness front (2 bushings 28-34-68) SKV	13/11	70	1302	28*34*68
MC091088	Leaf spring MSF52 / MC091088 Fuso 5t/HD120 undermain 13*70 front SKV	13	70	1312	
MC091088-V	Leaf spring MSF52V / MC091088-V Fuso 5t undermain tapered thickness front SKV	14/12	70	1312	
MC090645	Leaf spring 48213-3V630 / MSF53/ MC090645 FUSO/ HINO 300 /UD 5T 3-rd with clamps rear SKV	13	70	1100	
MK315837	Leaf spring MSF81 / MK315837 13*80 Fuso 8t main front (2 bushings 30-36-78) SKV	13	80	1400	30*36*78
MK315839	Leaf spring MSF82 / MK315839 13*80 Fuso 8t undermain front SKV	13	80	1410	
MK315117	Leaf spring MSR51 / MK315117 / MC412186 Fuso 5t/HD120 main 13*70 rear (2 bushings 28-34-68) SKV	13	70	1302	28*34*68
MK315005	Leaf spring MSR5160 / MK315005 13*60 Fuso 5T main rear (2 bushings 28-34-68) SKV	13	60	1302	28*34*68
MC412186-V	Leaf spring MSR51V / MK315117-V / MC412186-V Fuso 5t main tapered thickness rear 2 bushings 28-34-68 SKV	14/12	70	1302	28*34*68
MK315620	Leaf spring MSR52 / MK315620 Fuso 5t/HD120 undermain 13*70 rear SKV	13	70	1312	
MK315007	Leaf spring MSR5260 / MK315007 13*60 Fuso 5T undermain rear SKV	13	60	1312	
MK315620-V	Leaf spring MSR52V / MK315620-V Fuso 5t undermain tapered thickness rear SKV	15/13	70	1312	
55021-06D10	Leaf spring NSF2V №1 / 55021-06D10 14*8*70 N-Atlas H41 main rear bushing 28-34-68+bushings D40 SKV	14/8	70	1240	28*34*68 / 43*40*36

Leaf springs




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
55022-06D10	Leaf spring NSF2V №2 / 55022-06D10 14*8*70 N-Atlas H41 undermain rear SKV	14/8	70	1260	
55023-06D10	Leaf spring NSF2V №3 / 55023-06D10 15*8*70 N-Atlas H41 3-rd leaf with clamp SKV	15/8	70	1250	
S481-016330	Leaf spring S481-016330 18*70 HINO 500 main front (bushings 25-31-68) SKV	18/12	70	1300	25*31*68
S481-127090	Leaf spring S481-127090 20*70 HINO 500 undermain front SKV	20/10	70	1315	
S4810-13800	Leaf spring S4810-13800 12x90 HINO 700 main Front (bushings 30*38*88) SKV	12	90	1500	30*38*88
S4810-45770	Leaf spring S4810-45770 20x80 HINO 500 GH8#/FG8# 09~ 3-rd leaf with clamps front SKV	20/13	80	1500	
S4811-27720	Leaf spring S4811-27720 12x90 HINO 700 undermain Front SKV	12	90	1520	
54010-Z3007F	Leaf spring USF11 / 54010-Z3007F 12*90 N.-Diesel 10t main front (2 bushings 30-36-88) SKV	12	90	1554	30*36*88
54010-Z3007F2	Leaf spring USF12 / 54010-Z3007F2 12*90 N.-Diesel 10t undermain front SKV	12	90	1564	
55211-Z9418	Leaf spring USR51 / 55211-Z9418 11*70 Nissan UD 5t main rear (bushing 28-34-68) SKV	11	70	1450	28*34*68
55212-Z9419	Leaf spring USR52 / 55212-Z9419 13*70 Nissan UD 5t undermain rear SKV	13	70	1450	
W001-34-011	Leaf spring W001-34-011 8*70 Mazda main front (silenblocks 16*33) SKV	8	70	1100	33*16*76 / 38*19*46
W023-28-011	Leaf spring W023-28-011 Mazda main rear (silenblocks) SKV	11	70	1200	76*33*16 / 48*39*19

Spring assemblies




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm	Number of leaves (n)
A091-2912013-01	Spring assy A091-2912013-01 Bogdan rear (silentblocks) SKV	10	70	1350	81*42*18 / 42*40*16	6
A091-2902013-01	Spring assy A091-2902013-01 10*70 Bogdan front (silentblocks) SKV	10	70	1300	81*42*16 / 42*40*16	7
55100-5K500	Spring assy (with helper) 55100-5K500/501 10/11x70 HD65/72/78/MIGHTY 04~ rear (2 bushings 28*34*68) SKV	10/11	70	1250	28*34*68	6 / 5 (with helper)
55100-5K500U	Spring assy (with helper) 55100-5K500U reinforced 10/11x70 HD65/72/78 04~ rear (2 bushings 28*34*68) SKV	10/11	70	1250	28*34*68	7 / 5 (with helper)
55100-62002	Spring assy (with helper) 55100-62002 11*70 HYUNDAI HD120 04~ rear (2 bushings 28*34*68) SKV	11	70	1300	28*34*68	10 / 7 (with helper)
54100-5A301	Spring assy 54100-5A301 11*70 HYUNDAI County 04~ front (2 bushings + 2 silentblocks) SKV	11	70	1205	43*40*36 / 60*19*46	7 / 5 (with helper)
54100-5A301U	Spring assy 54100-5A301U reinforced 11*70 HYUNDAI County 04~ front (2 bushings + 2 silentblock) SKV	11	70	1205	43*40*36 / 60*19*46	6
54100-5K500	Spring assy 54100-5K500 11/10x70 HD45/65/72/78/MIGHTY/HD35/75 04~ front (2 bushings + silentblock) SKV	10/11	70	1210	43*40*36 / 42*44*16	5
54100-5K500U	Spring assy 54100-5K500U reinforced 11/10x70 HD65/72/78/MIGHTY 04~ front (2 bushings + silentblock) SKV	10/11	70	1210	43*40*36 / 42*44*16	6
54100-5K501	Spring assy 54100-5K501 11/10x70 HD45/65/72/78/MIGHTY/HD35/75 10~ front (2 silentblocks) SKV	10/11	70	1210	42*44*16	5
54100-6A010	Spring assy 54100-6A010 11*70 HD120 04~ front LH (2 bushings 28*34*68/bracket+pin) SKV	10/11	70	1310	28*34*68	7
54110-4E602	Spring assy 54110-4E602 3/13*70 BONGO III 2.9 `06~ front (silentblock + bushing 38*44*68) SKV	13	70	1200	38*44*68 / 76*33*16	2
54110-6A011	Spring assy 54110-6A011 11*70 HD120 04~ front RH (2 bushings 28*34*68/bracket+pin) SKV	11	70	1310	28*34*68	7
55100-4B700	Spring assy 55100-4B700 8/7/12x60 HYUNDAI H100 Porter 96~ rear (1 bushing 28*34*58) SKV	8/7/1 2	60	1200	28*34*58	5
55100-4B700+	Spring assy 55100-4B700 + H100 Porter 96~ reinforced (6 leaves) rear (bushing 28*34*58) SKV	8/7/1 2	60	1200	28*34*58	6
55100-5A300	Spring assy 55100-5A300 11*70 HYUNDAI County 04~ rear (2 bushings + 2 silentblocks) SKV	11	70	1360	43*40*36 / 60*19*46	6
55100-5A300U	Spring assy 55100-5A300U reinforced (7 leaves) 11*70 HYUNDAI County 04~rear (2 bushings + 2 silentblocks) SKV	11	70	1360	43*40*36 / 60*19*46	7
55110-4E700	Spring assy 55110-4E700 9/8/7/18*70 BONGO III 2.9 `04~ rear (0) (silentblock + bushing 38*44*68) SKV	9/8/ 7/18	70	1200	38*44*68 / 76*33*16	7
48210-E0330	Spring assy (with helper) 48210-E0330 18/16/15/13x70 HINO 500 rear (bushings 30-36-68) SKV	18/16 /15/1 3	70	1290	30*36*68	4 / 5 (with helper)
8-97122-382-0	Spring assy (with helper) 8-97122-382-0 10/11/8/7*70 Isuzu ELF NPR/NQR rear (silentblock) SKV	10/11 /8/7	70	1350	42*18*81 / 40*44*16	6 / 6 (with helper)
48210-E0E10	Spring assy 48210-E0E10 / S4822-05091 18*90 HINO 700 Rear SKV	18	90	150		12



Spring assemblies


Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm	Number of leaves (n)
8-98017-566-1	Spring assy (with helper) 8-98017-566-1 11/12/13/14*100 Isuzu FVR34 rear (bushing 32*38) SKV	11/12/13/14	100	1660	32*38*98	7 / 8 (with helper)
8-98064-447-0	Spring assy (with helper) 8-98064-447-0 11/17*70 Isuzu FSR90 rear (2bushings 25*30*68) SKV	11	70	1300	25*30*68	8 / 5 (with helper)
8-98239-514-0	Spring assy (with helper) 8-98239-514-0 8/9/11/12*70 Isuzu NPR75 rear (silentblock) L=1300 SKV	8/9/11/12	70	1300	42*18 / 40*16	7 / 7 (with helper)
1-51130-962-0	Spring assy 1-51130-962-0 13/14/16*80 Isuzu 10t CYZ51 LHD front (2 bushings 32*42*78) SKV	13/14/16	80	1600	32*42*78	9
1-51410-118-1	Spring assy 1-51410-118-1 10/13*70 Isuzu 5t. Frear/FSR/FRD 97~ rear (bushing 25*30*68) L=1380 SKV	10/13	70	1380	25*30*68	7
48110-3V700	Spring assy 48110-3V700 10/70 Hino 300 front (2 bushings 25-31-68) SKV	10	70	1240	25*31*68	7
48110-E0G00	Spring assy 48110-E0G00 HINO 500 (22.5) front SKV	20	80	1480	30*38*78	4
48110-E0J80	Spring assy 48110-E0J80 20/18/16/15*70 HINO 500 front (bushings 25-31-68) SKV	20/18/16/15	70	1300	25*31*68	4
48110-E0F30	Spring assy 48110-E0F30 10/12x90 HINO 700 Front (bushings 30*38*88) SKV	10/12	90	1500	30*38*88	12
48210-3V620	Spring assy 48210-3V620 11/70 Hino 300 rear (2 bushings 25-31-68) with helper SKV	11	70	1306	25*31*68	6 / 5 (with helper)
48210-E0D50	Spring assy 48210-E0D50 HINO 500 (22.5) rear SKV	12	90	1400	38*46*88	12 / 10 (with helper)
8-97033-427-1	Spring assy 8-97033-427-1/428-1 13*70 Isuzu ELF NPR 93~ front (silentblocks) SKV	13	70	1140	81*42*16 / 42*40*16	4
8-97033-429-3	Spring assy 8-97033-429-3 11/14*70 Isuzu ELF NPR/NQR 99~ front 3 leaves (silentblocks) SKV	11/14	70	1140	81*42*16 / 42*40*16	3
8-97096-544-2	Spring assy 8-97096-544-2 Isuzu ELF NPR/NQR 93~ front 10/11/8/7x70 (silentblocks) SKV	10/11	70	1300	81*42*16 / 42*40*16	6
8-98001-533-0	Spring assy 8-98001-533-0/8-98079-881-0 9*60 Isuzu NLR/NMR55/85 08~ front (bushings. 40*43*30) SKV	9	60	1140	43*40*30	6
8-98001-543-1	Spring assy 8-98001-543-1 11/20*70 Isuzu NLR/NMR55/85 08~ rear (silentblocks 42*16, bushings. 43*40) SKV	11/11/20	70	1200	silentblocks 42*16 bushings 43*40	3
8-98063-483-0	Spring assy 8-98063-483-0 17/19*70 Isuzu FSR90 front (2bushings 25*30*68) SKV	17/19	70	1300	25*30*68	3
8-98069-483-0	Spring assy 8-98069-483-0 21/24*80 Isuzu FVR34 front (bushings 32*38*78) SKV	21/24	80	1600	32*38*78	3
8-98159-622-0	Spring assy 8-98159-622-0 35/18*90 Isuzu CYZ52 Rear SKV	35/18	90	1600		5
48110-37590	Spring assy DPF5 / 48110-37590/ 11/13*70 Hino Dutro/Dyna/Isuzu 5t front 25*31 SKV	11/13	70	1200	25*31*68	6
48120-3152	Spring assy HPF5 / 48120-3152 11/13*70 Hino FD1/2/3H#/I# 89~ 5t front (2 bushings 25-31-68) SKV	11/13	70	1300	25*31*68	6
48230-5320	Spring assy HPR5 / 48230-5320 11/13*70 Hino FD1/2/3H#/I# 89~ 5t rear (1 bushing 30-36-68) SKV	11/13	70	1440	30*36*68	7

Spring assemblies




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm	Number of leaves (n)
1-51130-088-0	Spring assy IPF5 / 1-51130-088-0 Isuzu Frear/FRD/FSR 93~ 5t front 7 leaves 2 bushings 25-30-68 SKV	13	70	1340	25*30*68	7
1-51410-294-0	Spring assy IPR2940 / 1-51410-294-0 20*90 Isuzu 10t CYZ51 (LHD) rear SKV	20	90	1530		9
1-51410-123-1	Spring assy IPR5 / 1-51410-123-1 / 13*70 Isuzu 5t rear (bushing 25-30-68) L=1430 SKV	13	70	1430	25*30*68	7
MB391393V	Spring assy MB391393V 15*70 Canter FE335/37/435/37/39 rear tapered thickness 2 bushings 28-34-68 SKV	15/8	70	1250	28*34*68	3
MK470171	Spring assy MK470171 11*70 FUSO CANTER front (bushings 43-40-36) SKV	11	70	1208	43*40*36	5
MK470174	Spring assy MK470174 11*14*70 FUSO CANTER rear (2 bushings 28-34-68) with helper SKV	11/14	70	1302	28*34*68	4 + 5 (with helper)
MB294469	Spring assy MPF2FA / MB294469 10*70 Canter FE# front (bushings) SKV	10	70	1206	43*40*36	6
MC090304	Spring assy MPF5 d-10.5mm / MC090304 11/13*70 Fuso 5t FK6# front (2 bushings 28-34-68) SKV	11/13	70	1302	28*34*68	6
MC090304	Spring assy MPR5 d-12.5mm/ MC090304 13*70 Fuso 5t FK6# rear (2 bushings 28-34-68) SKV	13	70	1302	28*34*68	6
8-97135-078-0	Spring assy (helper) 8-97135-078-0 10*70 Isuzu ELF NPR/NQR rear SKV	10	70	970		6
MK470174	Spring assy (helper) DRS-MK470174 FUSO Canter rear SKV	11/12	70	1060		5
48260-3500	Spring assy (helper) HPR5HA / 48260-3500 11/13*70 Hino FD1/2/3H#/J# 89~ 5t rear SKV	11/13	70	1020		7
MK382259	Spring assy MK382259 14*110 Canter FE70/72/74 (2 leaves + 2 spacer plates) SKV	14	110	1050		2

Leaf springs (Europe)




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm
1479518-1SKV	Leaf spring 1479518-1SKV 28*90 Scania P-Series 04~ main Front SKV	28	90	1820	M28*36*89
1479518-2SKV	Leaf spring 1479518-2SKV 28*90 Scania P-Series 04~ undermain Front SKV	28	90	1840	
1547824-1SKV	Leaf spring №1 1547824-1SKV / 90199001 30*90 Scania R-Series 04~ Rear SKV	30	90	1590	
1547824-2SKV	Leaf spring №2 1547824-2SKV / 90199002 30*90 Scania R-Series 04~ Rear SKV	30	90	1590	
09635001SKV	Leaf spring 09635001SKV / 1635305 №1 830x830mm 1/26x90mm VOLVO FM/FH Series Rear	26	90	1660	
09635002SKV	Leaf spring 09635002SKV / 1635322 №2 810x810mm 1x26x90 mm VOLVO FM/FH Series Rear	26	90	1620	
09639003SKV	Leaf spring 09639003SKV / 1635357 №3/4 90x690/690 mm VOLVO FM/FH Series Rear	26	90	1380	
1635244SKV	Leaf spring 1635244SKV / 09635005 26*90/950mm (with clamps) VOLVO TRUCK FM# (dump truck) Rear	26	90	950	
257907-1SKV	Leaf spring 257907-1SKV / 09722001 30*100/990*900mm VOLVO TRUCK FH/FM main Front	30	100	1890	M52*20*110
257907-2SKV	Leaf spring 257907-2SKV / 09722002 30*100/990*920mm VOLVO TRUCK FH/FM undermain Front	30	100	1910	
257933-1SKV	Leaf spring 257933-1SKV / 09746001 28*100/950*1090mm VOLVO TRUCK FM main Front	28	100	2040	M52*20*100
81434026292-2SKV	Leaf spring 81434026292-2SKV / 73006002 25*90/925*745mm MAN TGA# undermain Front	25	90	1670	
9443200702-1SKV	Leaf spring 9443200702-1SKV / 33872001 26*90 MERCEDES ACTROS 3341 main Front	26	90	1800	62*24*96
9483201405-1SKV	Leaf spring 9483201405-1SKV / 33839001 №1 41*100 MB Actros, Actros MP2/MP3, Axor 2 main Rear	41	100	1670	
9483201405-2SKV	Leaf spring 9483201405-2SKV / 33839002 №2 41*100 MB Actros, Actros MP2/MP3, Axor 2 undermain Rear	41	100	1570	
9483201405-3SKV	Leaf spring 9483201405-3SKV / 33839003 №3 41*100 MB Actros, Actros MP2/MP3, Axor 2 Rear	41	100	1570	

Spring assemblies (Europe)




Article	Nomenclature	h, mm	H, mm	L, mm	Silentblock/ Bushing (K), mm	Number of leaves (n)
257658SKV	Spring assy 257658SKV / 09639000 VOLVO FM/FH 26*90 Rear 11 leaves SKV	26	90	1660		11
09714000SKV	Spring assy 09714000SKV / 257928 22/25*100 VOLVO FH12/FM 93~ Front	22/25	100	1590	20*50*110	3
09720000SKV	Spring assy 09720000SKV / 257932 32/26*100 VOLVO FH12 FH/FM 6x4 93~ Front	26/32	100	900/ 990	20*50*110	3
1479518SKV	Spring assy 1479518SKV / 90138000 28*90 Scania P-Series 04~ Front 4 leaves (bushings 36xM25x88)	28	100	910/ 910	M28*36*89	4
1547824SKV	Spring assy 1547824SKV / 90199000 30*90 Scania R-Series 04~ Rear 8 leaves	30	90	795/ 795		8
257933SKV	Spring assy 257933SKV / 09746000 VOLVO FM7/12/13/16 28x100x1090x950 Front 3 leaves SKV	28	100	1090/ 950	20*52*110	3
81434026258SKV	Spring assy 81434026258SKV / 72988000 30*90x925/925 MAN TGA/TGS/TGX Front 2 leaves	30	90	925/ 925	24*65*94	2
A6593200502SKV	Spring assy A6593200502SKV / 33666000 23*90 Mercedes ACTROS AXOR Front 4 leaves	23	90	1800	24*62*96	4
257927SKV	Spring assy 257927SKV / 09712000 32*100/900*990mm VOLVO FH/FM Front 2 leaves	32	100	990	52*20*110	2
9443200702SKV	Spring assy 9443200702SKV / 33872000 29*90x970/830mm MERCEDES ACTROS 3341 Front 4 leaves	29	90	1800	62*24*96	4
9483201405SKV	Spring assy 9483201405SKV / 33839000 41/47*100x835/835mm MB Actros, MP2/MP3, Axor 2 Rear 5 leaves	41	100	1670		5
A0003200202SKV	Spring assy A0003200202SKV / 33818000 28*90/900*900mm MERCEDES ACTROS/ATEGO Front 2 leaves	28	90	1800	62*24*96	2
81434026325SKV	Spring assy (1 leaf) 81434026325SKV / 73042000 41*90 MAN 7,5t Front	30	90	1850	65*24*95	

Balancer repair kit




Article	Nomenclature
2262363SKV	Balancer repair kit 2262363SKV SCANIA

Wheel bolt assemblies




Article	Nomenclature	Bolt			Threaded bushing		
		L ₁ , mm	m ₁ , mm	Nut (m ₂), mm	L ₂ , mm	m ₃ , mm	Nut m ₄ , mm
0442A-E0080	Wheel bolt 0442A-E0080 HINO 500 rear LH M22*1.5*99 SKV	99	M22x1.5	M22x1.5/33			
0443A-E0110	Wheel bolt 0443A-E0110 HINO 500 front LH M22*1.5*83 SKV	83	M22x1.5	M22x1.5/33			
0443A-E0110	Wheel bolt 0443A-E0110 HINO 500 front RH M22*1.5*83 SKV	83	M22x1.5	M22x1.5/33			
1-42337-066-1	Wheel bolt 1-42337-066-1 / 1-42337-066-2 / CYZ51 / rear BW71L ISUZU SKV	93	M22x1.5	M22x1.5/33			
1-42337-066-1	Wheel bolt 1-42337-066-1 / 1-42337-066-2 / CYZ51 / rear BW71R ISUZU SKV	93	M22x1.5	M22x1.5/33			
1-42337-067-1	Wheel bolt 1-42337-067-1 / CYZ51 / front BW70L ISUZU SKV	103,5	M22x1.5	M22x1.5/33 M22x1.5/32			
1-42337-067-1	Wheel bolt 1-42337-067-1 / CYZ51 / front BW70R ISUZU SKV	103,5	M22x1.5	M22x1.5/33 M22x1.5/32			
8-94383-436-2	Wheel bolt 8-94383-436-2 NLR55, NMR85, NPR, NQR front RH SKV	78	M18x1.5 / M20x1.5	M18x1.5/41 M20x1.5/30			
8-94383-437-2	Wheel bolt 8-94383-437-2 NLR55, NMR85, NPR, NQR front LH SKV	78	M18x1.5 / M20x1.5	M18x1.5/41 M20x1.5/30			
8-97081-584-2	Wheel bolt 8-97081-584-2 NQR 71/75 rear RH 93.5 SKV	93	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	62	M20x1.5	M30x1,5
8-97081-585-2	Wheel bolt 8-97081-585-2 NQR 71/75 rear LH 93.5 SKV	93	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	62	M20x1.5	M30x1,5
8-97131-283-1	Wheel bolt 8-97131-283-1 NQR 71/75 front RH 85.5 SKV	86	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/32			
8-97131-284-1	Wheel bolt 8-97131-284-1 NQR 71/75 front LH 85.5 SKV	86	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/32			
BN02L	Wheel bolt BN02L FUSO/ISUZU 5t. rear LH SKV	82	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN02R	Wheel bolt BN02R FUSO/ISUZU 5t. rear RH SKV	82	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN03L	Wheel bolt BN03L ISUZU 5t. front LH SKV	90	M22x1.5 / M24x1.5	M22x1.5/32 M24x1.5/41			
BN03R	Wheel bolt BN03R ISUZU 5t. front RH SKV	90	M22x1.5 / M24x1.5	M22x1.5/32 M24x1.5/41			
BN04 L	Wheel bolt BN04L ISUZU/FUSO/UD 10t. rear LH SKV	102	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/32	63	M20x1.5	M30x1,5
BN04 R	Wheel bolt BN04R ISUZU/FUSO/UD 10t. rear RH SKV	102	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/32	63	M20x1.5	M30x1,5
BN05L	Wheel bolt BN05L ISUZU 10t. front LH M20x1.5 SKV	102	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/36			

Wheel bolt assemblies




Article	Nomenclature	Bolt			Threaded bushing		
		L ₁ , mm	m ₁ , mm	Nut (m ₂), mm	L ₂ , mm	m ₃ , mm	Nut m ₄ , mm
BN05L2	Wheel bolt BN05L2 ISUZU 10t. front LH M24x1.5 SKV	103	M24x1.5 / M22x1.5	M24x1.5/41 M22x1.5/32			
BN05R	Wheel bolt BN05R ISUZU 10t. front RH M20x1.5 SKV	102	M22x1.5 / M20x1.5	M20x1.5/41 M22x1.5/36			
BN05R2	Wheel bolt BN05R2 ISUZU 10t. front RH M24x1.5 SKV	103	M24x1.5 / M22x1.5	M24x1.5/41 M22x1.5/32			
BN07L	Wheel bolt BN07L UD 5t. rear LH SKV	88	M20x1.5 / M20x1.5	M20x1.5/30 M30x1.5/41	63	M20x1.5	M30x1,5
BN07R	Wheel bolt BN07R UD 5t. rear RH SKV	88	M20x1.5 / M20x1.5	M20x1.5/30 M30x1.5/41	63	M20x1.5	M30x1,5
BN08L	Wheel bolt BN08L UD 5t. front LH SKV	88	M20x1.5 / M20x1.5	M20x1.5/30 M20x1.5/41			
BN08R	Wheel bolt BN08R UD 5t. front RH SKV	88	M20x1.5 / M20x1.5	M20x1.5/30 M20x1.5/41			
BN09L	Wheel bolt BN09L HINO 5t. front LH SKV	87	M22x1.5 / M20x1.5	M22x1.5/32 M20x1.5/41			
BN09R	Wheel bolt BN09R HINO 5t. front RH SKV	87	M22x1.5 / M20x1.5	M22x1.5/32 M20x1.5/41			
BN10L	Wheel bolt BN10L HINO500 0442A-E0060 HINO 5t. rear LH SKV	87	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN10R	Wheel bolt BN10R HINO500 0442A-E0060 HINO 5t. rear RH SKV	87	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN12L	Wheel bolt BN12L HINO 10t. rear LH SKV	99	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN12R	Wheel bolt BN12R HINO 10t. rear RH SKV	99	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	63	M20x1.5	M30x1,5
BN13L	Wheel bolt BN13L HINO 10t. front LH SKV	102	M24x1.5 / M22x1.5	M22x1.5/32 M24x1.5/41			
BN13R	Wheel bolt BN13R HINO 10t. front RH SKV	102	M24x1.5 / M22x1.5	M22x1.5/32 M24x1.5/41			
BN20L	Wheel bolt BN20L HINO/FUSO Euro 10t. universal LH SKV	129	M30x1.5 / M22x1.5	M22x1.5/36 M30x1.5/41			
BN20R	Wheel bolt BN20R HINO/FUSO Euro 10t. universal RH SKV	129	M30x1.5 / M22x1.5	M22x1.5/36 M30x1.5/41			
BN21L	Wheel bolt BN21L HINO/FUSO Euro 10t. universal L=138 mm for 12 mm SKV	138	M30x2.0 / M22x2.0	M22x2.0/32 M30x2.0/41			
BN21R	Wheel bolt BN21R HINO/FUSO Euro 10t. universal L=138 mm for 12 mm SKV	138	M30x2.0 / M22x2.0	M22x2.0/32 M30x2.0/41			

Wheel bolt assemblies




Article	Nomenclature	Bolt			Threaded bushing		
		L ₁ , mm	m ₁ , mm	Nut (m ₂), mm	L ₂ , mm	m ₃ , mm	Nut m ₄ , mm
BW19L	Wheel bolt BW19L NPR NEW rear LH SKV	78	M18x1.5 / M19x1.5	M19x1.5/30 M27x1.5/41	60	M18x1.5	M27x1.5
BW19R	Wheel bolt BW19R NPR NEW rear RH SKV	78	M18x1.5 / M19x1.5	M19x1.5/30 M27x1.5/41	60	M18x1.5	M27x1.5
BW30L	Wheel bolt BW30L MMC CANTER rear LH nut 38 SKV	83	M19x1.5 / M19x1.5	M19x1.5/27 M28x1.5/38	61	M19x1.5	M28x1.5
BW30R	Wheel bolt BW30R MMC CANTER rear RH nut 38 SKV	83	M19x1.5 / M19x1.5	M19x1.5/27 M28x1.5/38	61	M19x1.5	M28x1.5
BW31L	Wheel bolt BW31L MMC CANTER front LH nut 38 SKV	83	M19x1.5 / M19x1.5	M19x1.5/27 M19x1.5/38			
BW31R	Wheel bolt BW31R MMC CANTER front RH nut 38 SKV	83	M19x1.5 / M19x1.5	M19x1.5/27 M19x1.5/38			
BW32L	Wheel bolt BW32L ISUZU ELF 1,5t. rear LH nut 35 SKV	70	M16x1.5 / M16x1.5	M16x1.5/24 M25x1.5/35	56	M16x1.5	M25x1.5
BW32R	Wheel bolt BW32R ISUZU ELF 1,5t. rear RH nut 35 SKV	70	M16x1.5 / M16x1.5	M16x1.5/24 M25x1.5/35	56	M16x1.5	M25x1.5
BW33L	Wheel bolt BW33L ISUZU ELF 1,5t. front LH nut 35 SKV	52	M16x1.5	M16x1.5/35			
BW33R	Wheel bolt BW33R ISUZU ELF 1,5t. front RH nut 35 SKV	52	M16x1.5	M16x1.5/35			
BW44L	Wheel bolt BW44L CANTER front LH nut 38 SKV	52	M19x1.5	M19x1.5/38			
BW44R	Wheel bolt BW44R CANTER front RH nut 38 SKV	52	M19x1.5	M19x1.5/38			
BW48L	Wheel bolt BW48L HINO 10t. LH SKV	109	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	76	M20x1.5	M30x1.5
BW48R	Wheel bolt BW48R HINO 10t. RH SKV	109	M22x1.5 / M20x1.5	M22x1.5/32 M30x1.5/41	76	M20x1.5	M30x1.5
MC891568	Wheel bolt BW62L Rear LH MC891568/MK501080/MB308673 MMC CANTER M20*1.5*83 SKV	83	M20x1.5 / M19x1.5	M19x1.5/27 M30x1.5/41	63	M20x1.5	M30x1.5
MC891569	Wheel bolt BW62R Rear RH MC891569/MK501079/MB308672 MMC CANTER M20*1.5*83 SKV	83	M20x1.5 / M19x1.5	M19x1.5/27 M30x1.5/41	63	M20x1.5	M30x1.5
MC891568	Wheel bolt BW63L Front LH MC891568/MK501080/MB308673 MMC CANTER M20*1.5*83 SKV	83	M20x1.5 / M19x1.5	M19x1.5/27 M20x1.5/41			
MC891569	Wheel bolt BW63R Front RH MC891569/MK501079/MB308672 MMC CANTER M20*1.5*83 SKV	83	M20x1.5 / M19x1.5	M19x1.5/27 M20x1.5/41			
90942-02071	Wheel bolt BW68L Front LH 90942-02071 HINO 300 SKV	46	M20x1.5	M20x1.5/41			

Wheel bolt assemblies




Article	Nomenclature	Bolt			Threaded bushing		
		L ₁ , mm	m ₁ , mm	Nut (m ₂), mm	L ₂ , mm	m ₃ , mm	Nut m ₄ , mm
90942-02072	Wheel bolt BW68R Front RH 90942-02072 HINO 300 SKV	46	M20x1.5	M20x1.5/41			
90942-02071	Wheel bolt BW69L Rear LH 90942-02071 HINO 300 SKV	46	M20x1.5	M30x1.5/41	54.5	M20x1.5	M30x1.5
90942-02072	Wheel bolt BW69R Rear RH 90942-02072 HINO 300 SKV	46	M20x1.5	M30x1.5/41	54.5	M20x1.5	M30x1.5
1749034	Wheel nut with cup and right thread Scania SKV			7/8" H=30.8 SW33			
03.296.33.14.1 SKV	Wheel bolt 03.296.33.14.1SKV / 03.296.33.14.1 (BPW)	90/45	M22x1.5				
03.296.33.12.1SKV	Wheel bolt 03.296.33.12.1SKV M22x1.5x97/62 (BPW)	97/62	M22x1.5				
1368690SKV	Wheel bolt 1368690SKV 30x81x70 mm Front Scania	81/70	7/8"-11BSF				
1528655SKV	Wheel bolt 1528655SKV / 1528655 SCANIA		7/8"x11BSFx 112, 5/102-10, 9				
21147687SKV	Wheel bolt 21147687SKV / 20524942 Rear VOLVO	115/87/125	M22x1.5				
81455010176SKV	Wheel bolt 81455010176SKV / A0004013771 / 81455010141 Rear MAN/MERCEDES	110/72/120	M22x1.5				
1368694SKV	Wheel bolt 1368694SKV 7/8" L=109/97/71 RHT Rear Scania	109/97/71 RHT	7/8"				
1868668SKV	Wheel bolt 1868668SKV 7/8" x 11 BSF x 110 L=98 mm Rear Scania	98	7/8" x 11 BSF x 110				
5175545000	Wheel bolt 51755-45000 HD45/HD65/HD72/HD78 front LH (nut 38) SKV	77	M19x1.5	M19x1.5/27 M19x1.5/38			
5175545000	Wheel bolt 51755-45000 HD45/HD65/HD72/HD78 front RH (nut 38) SKV	77	M19x1.5	M19x1.5/27 M19x1.5/38			
5175545200	Wheel bolt 51755-45200 HD45/HD65/HD72/HD78 front LH (nut 41) SKV	83	M19x1.5	M19x1.5/27 M19x1.5/41			
5175545200	Wheel bolt 51755-45200 HD45/HD65/HD72/HD78 front RH (nut 41) SKV	83	M19x1.5	M19x1.5/27 M19x1.5/41			
5275545000	Wheel bolt 52755-45000 (L) HD45/HD65/HD72/HD78 rear LH (nut 38) SKV	101	M19x1.5 / M22x2.5	M19x1.5/27 M22x2.5/38			

Wheel bolt assemblies




Article	Nomenclature	Bolt			Threaded bushing		
		L ₁ , mm	m ₁ , mm	Nut (m ₂), mm	L ₂ , mm	m ₃ , mm	Nut m ₄ , mm
5277545000	Wheel bolt 52755-45000 (R) HD45/HD65/HD72/HD78 rear RH (nut 38) SKV	101	M19x1.5 / M22x2.5	M19x1.5/27 M22x2.5/38			
5275545210	Wheel bolt 52755-45210 HD45/HD65/HD72/HD78 rear LH (nut 41) SKV	100	M19x1.5 / M22x2.5	M19x1.5/27 M22x2.5/41			
5275545210	Wheel bolt 52755-45210 HD45/HD65/HD72/HD78 rear RH (nut 41) SKV	100	M19x1.5 / M22x2.5	M19x1.5/27 M22x2.5/41			




Spring pins

Article	Nomenclature	L ₁ , mm	L ₂ , mm	Thread (m), mm	D, mm
54224-62000	Spring pin HD120 54224-62000 (28*129) (FR LS) SKV		129		28
55223-45002	Spring pin HD65/72/78 55223-45002 (28*127.5) (RR LS) rear SKV		127,5		28
55224-5H000	Spring pin HD65/72/78 55224-5H000 (28*120.5) (RR LS) SKV		120,5		28
54223-62000	Spring pin HD65/72/78/120 54223-62000 (28*117) front/rear SKV		117		28
1-51361-016-0	Spring pin 1-51361-016-0/1-017-0/9-51361-034-1/48423-1890(25*115) Hino 300/Isuzu 5t rear/front SKV		115		25
48423-1640	Spring pin front HINO300/500 48423-1640/48423-2430 (25*105*129) SKV	105	129		25
48423-1650	Spring pin front rear HINO300/500 48423-1650/48423-2440 (25*91*115) SKV	91	115		25
MC031390	Spring pin FUSO 10T front MC031390/MC009257/MK300383/SP13 (32*152) SKV		152		32
MC031391	Spring pin FUSO 10T front MC031391 MK300384 (32*152) SKV		152		32
MC035277	Spring pin FUSO 5T rear MC035277 (28*120) SKV		120		28
MC420078	Spring pin FUSO 5T rear/front MC420078 (28*116) SKV		116		28

Spring pins




Article	Nomenclature	L ₁ , mm	L ₂ , mm	Thread (m), mm	D, mm
MC403611	Spring pin FUSO 5t front MC403611 (28*95*128) SKV	95	128		28
MC092193	Spring pin FUSO 5T front MC092193 (28*92*124) SKV	92	124		28
MC404416	Spring pin FUSO 8t front MC404416 (30*114*147) SKV	114	147		30
MC420079	Spring pin FUSO 8t front MC420079 (30*138) SKV		138		30
MB035277	Spring pin FUSO CANTER 3t rear MB035277/160870 (28*139) SKV		139		28
MC114570	Spring pin FUSO CANTER Fe4## FE5## rear MC114570 (28*117) SKV		117		28
MB035281	Spring pin FUSO CANTER rear MB035281/SP36 (28*80*124) SKV	80	124		28
MC092652	Spring pin FUSO front MC092652/SP38 (28*112) SKV		112		28
48423-2150	Spring pin HINO 10T rear 48423-2150 (38*158) SKV		158		38
48423-1790	Spring pin HINO 10t front 48423-1790/48423-2300 (30*148) SKV		148		30
48423-2230	Spring pin HINO 10t front 48423-2230 (25*121*149) SKV	121	149		25
48423-2171	Spring pin HINO 3T front LF 48423-2171 SP07 (25*105*129) SKV	105	129		25
48423-1561	Spring pin HINO 7-8t front 48423-1561 (30*120*145) SKV	120	145		30
48423-1320	Spring pin HINO500/HINO 5t rear 48423-1320 (30*123) SKV		123		30
9-51361-014-0	Spring pin ISUZU 9-51361-014-0/SP39 (28*131) SKV		131		28
1-51161-014-0	Spring pin ISUZU 10t front 1-51161-014-0/1-51161-043-1/1-51161-031-0 (32*136) SKV		136		32
1-51161-043-1	Spring pin ISUZU 10t front 1-51161-043-1/ 1-51161-014-0 (32*136) SKV		136		32
1-51161-005-3	Spring pin ISUZU 5t front 1-51161-005-3 (25*90*119) SKV	90	119		25
8-94122-174-3	Spring pin ISUZU ELF 3t rear 8-94122-174-3 (25*122) SKV		122		25
8-94146-149-3	Spring pin ISUZU ELF 3T rear 8-94146-149-3 (25*82*120) SKV	82	120		25
1-51161-004-1	Spring pin ISUZU FORWARD 5t front 1-51161-004-1 (25*90*119) SKV	90	119		25
55224-Z1000	Spring pin NISSAN 10T rear 55224-Z1000/SP46 (35*160) SKV		160		35
54215-Z0002	Spring pin NISSAN 10t rear/front 54215-Z0002 (30*145) SKV		145		30
54215-00Z00	Spring pin NISSAN 10T front 54215-00Z00 / 55224-Z5001/SP35 (30*142) SKV		142		30
54215-Z5007	Spring pin NISSAN 5t rear 54215-Z5007 (28*114) SKV		114		28



Spring pins


Article	Nomenclature	L ₁ , mm	L ₂ , mm	Thread (m), mm	D, mm
54215-Z5003	Spring pin NISSAN 5t rear/front 54215-Z5003 (28*88*120) SKV	88	120		28
55226-0T005	Spring pin NISSAN H41, F23 front 55226-0T005 (28*76*120) SKV	76	120		28
0334105050SKV	Spring bolt 03.341.05.05.0SKV M30*3,5*170 mm 8,8 SKV	170	189	M30x3,5	30
1068680SKV	Spring bolt 1068680SKV / 7770165150 SKV M27*186	186	212	M27x2.0	30
03.340.14.25.0SKV	Central bolt 03.340.14.25.0 SKV M24X2 /260		260	M24X2	
03.340.15.23.0 SKV	Semi-spring pin 03.340.15.23.0 SKV M30x3,5x210 DIN 931/8,8	210	230	M30x3.5	30
03.340.15.27.0 SKV	Semi-spring pin 03.340.15.27.0 SKV M30x3,5x190 DIN 6914/8,8	190	210	M30x3.5	30
03.341.05.03.0 SKV	Semi-spring pin 03.341.05.03.0 SKV M30x200/40 mm	210	218	M30x3.5	30
355145SKV	Spring pin front Scania 355145 SKV / 2097427 M28x4x166	130	166	M28x4,0	28




Hub bearings

Article	Nomenclature	d, mm	D, mm	T, mm	C, mm	B, mm	r, mm
33118SKV	Hub bearing 33118 / 0264102300 90x150x45 SKV BPW	90	150	45	35	45	2.5
33213SKV	Hub bearing 33213/7174946/06324890046 (65x120x41)SKV Iveco	65	120	41	32	41	1.5
30213SKV	Hub bearing 30213JR rear inner/ 43215-22H00 / 9884-65107 / 9960-30-213 (FBJ) NQR71/75 SKV	65	120	24,75	23	20	2.5
32010SKV	Hub bearing 32010 / 43210-T6200 / 98845-0102 / 90368-50024 SKV	50	80	20	19	16	1.5
32011SKV	Hub bearing 32011 Atlas H40/Hino, Toyota BU162/162A/162D/172/182/Titan E,T Series/Canter SKV	55	90	23	22	19	2.0
32206SKV	Hub bearing 32206 J/32206JR/32206/90043-68020/5-09812-025-0/32273-03E00/MH043101 SKV	30	62	21,25	20.5	17	1.5

Hub bearings




Article	Nomenclature	d, mm	D, mm	T, mm	C, mm	B, mm	r, mm
32208SKV	Hub bearing 32208 J / 40210-76000 / 8-94248-077 / MS556512 NHR86~ SKV	40	80	24,75	23.5	20	2.0
32209SKV	Hub bearing 32209/0559-33-074/90043-66016 SKV	45	85	24.75	23.5	20	2.0
32210SKV	Hub bearing 32210/8-94368-553-0/01014-10534 SKV	50	90	24.75	23.5	20	2.0
32211SKV	Hub bearing 32211/Y7691-57291 SKV	55	100	26.75	25	21	2.5
32217SKV	Hub bearing 32217 / SZ366-85008 / 98848-5105/MH043078/ VKHB2080 SKV	85	150	38.5	30	36	2.0
32218SKV	Hub bearing 32218 /1-09812-080-0/MS556522/38440-49000 SKV	90	160	42.5	40	30	3.0
32219SKV	Hub bearing 32219 MH043014/9884-95102/MS556523 SKV	95	170	45.5	45.5	37	3.5
32310SKV	Hub bearing 32310/9884-50103/MS556586/MH043048 SKV	50	110	42,25	40	33	3.0
40KW01SKV	Hub bearing 40KW01/ST4080C/MH043064/MH043142/MH043092 SKV	40	80	34	34	27	1.3
414245SKV	Hub bearing 414245 210SA/1-09812-142-0 CX#/CY#/EX#/FRD/FTD/FTR 86~ SKV	68,262	136,525	41,275	41,275	31,75	
45KW01SKV	Hub bearing 45KW01 8-97034-255-0/40210-89TA4 NNR/NPR/NKR/NLR/NMR 93~ SKV	50	90	24,75	23.5	20	2.0
50KW02A SKV	Hub bearing 50KW02A/506349LFT/10/1BZ/(1B-9)/1-09812-234-0/1-09812-084-0 SKV	49,987	114,3	44,45	44,45	36,068	
48548SKV	Hub bearing 51701-44030/ 48548/10 H100 PORTER SKV	34,925	65,088	18,034	18,288	13,97	3.6
30310SKV	Hub bearing front inner HINO300 30310J/30310JR/30310/4T-30310/9884-50107/90033-66009 SKV	50	110	29,25	29	23	3.0
32307SKV	Hub bearing front outer HINO300 32307 / 90366-35023/35031/8-94452-448 SKV	35	80	32,75	31	27	2.5
1098122070SKV	Hub bearing front outer. 1-09812-207-0 / 20285 / ST4090 SKV	40	90	25,25	16	23	1,5
28985SKV	Hub bearing rear 9-00093-081-0 28985/20 NLR85/NMR85/NKR55 SKV	60,325	100	25.4	25.4	19,845	
28584SKV	Hub bearing rear 9-00093-082-0 28584/21 NLR85/NMR85/NKR55 SKV	52,388	92,065	24,608	25.4	19.845	
32215SKV	Hub bearing RR inner HINO300/500 (E4) 32215/MS556519/9884-75101/43210-L0700/01014-10584 SKV	75	130	33.25	31	27	2.5
32213SKV	Hub bearing RR outer HINO300/500 (E4) 32213/43210-47700/1-09812-129/MS556517 SKV	65	120	32.75	31	27	2.5
50KW01SKV	Hub bearing inner 50KW01/CR1084/MB025294/51701-45210 HD72/65/78/CANTER SKV	50	93,264	30,162	30,302	23,812	
30212SKV	Hub bearing rear inner HD65/72/78/COUNTY Fuso 4M50 52701-45010/30212 SKV	60	110	23.75	23	19	2.5
30211SKV	Hub bearing rear outer HD65/72/78/COUNTY 52703-45010/30211SKV	55	100	22,75	21	18	2.5



Hub bearings


Article	Nomenclature	d, mm	D, mm	T, mm	C, mm	B, mm	r, mm
28680SKV	Hub bearing rear outer 28680/22/90000936090 NQR71/75/90 SKV	55,562	97.63	24,608	24,608	19,446	3.6
30212SKV	Hub bearing rear outer Fuso Canter 30212 /9-00093-186 / 90043-70003/ MT321624 SKV	60	110	23,75	19	22	2
30210SKV	Hub bearing front inner 30210/MB025006/8-94452-449-0 County SKV	50	90	21.75	21	17	2.0
32207SKV	Hub bearing front outer 32207/MB025345/0559-33-075 HD65/72/35/75 Fuso 4M50 SKV	35	72	24.25	23	20	2.0
30207SKV	Hub bearing front outer HINO 300 30207/90366-35004/MB393957 County SKV	35	72	18,25	17	15	2.0



Clutch discs


Article	Nomenclature	Out D, mm	In D, mm	number of teeth (t)	M D, mm
TYD112	Clutch disc 236*150*21*29,8 TYD112 SKV	236	150	21	29.8
ISD101	Clutch disc 240*160*24*25,6 / ISD101 / 8-94159-975-0 SKV	240	160	24	25.6
ISD141U	Clutch disc 250*160*24*25.6 ISD141U / 8-98080-661-0 ELF NHR/NHS 95~ SKV	250	160	24	25.6
MZD063U	Clutch disc 260*170*12*28 / MZD063U / SE03-16-460B SKV	260	170	12	28
MFD013	Clutch disc 260*170*14*29,4 / MFD013 / ME500316 SKV	260	170	14	29.4
MFD013	Clutch disc 260*170*14*29,4 / MFD013U / ME500316 SKV	260	170	14	29.4
MFD084U	Clutch disc 260*170*14*29,4 / MFD084U Canter FB6, FE5, FE6 96-2001 SKV	260	170	14	29.4
MFD015	Clutch disc 275*175*14*29,4 / MFD015 / ME500185 SKV	275	175	14	29.4
TYD078Y	Clutch disc 275*175*21*29,8 / TYD078Y / 31250-36410 SKV	275	175	21	29.8

Clutch discs




Article	Nomenclature	Out D, mm	In D, mm	number of teeth (t)	M D, mm
ISD102	Clutch disc 275*180*24*25,6 / ISD102 / 5-31240-043-0 SKV	275	180	24	25.6
MZD074U	Clutch disc 300*180*12*28,0 / MZD074U / YM01-16-460A SKV	300	180	12	28
ISD035	Clutch disc 300*190*10*38,1 / ISD035/HND041U / 31250-3890 Ceramics SKV	300	190	10	38.1
ISD035	Clutch disc 300*190*10*38,1 / ISD035/HND041U/HND014Y / 31250-3890 / 1-31240-208-0 SKV	300	190	10	38.1
TYD119U	Clutch disc 300*190*14*32,4 / TYD119U / 31250-37041 SKV	300	190	14	32.4
ISD086U / MFD067U	Clutch disc 300*190*14*35,2 / ISD086U/MFD067U/ME521813/8-97320-355-0 Active hub SKV	300	190	14	35.2
MFD067U	Clutch disc 300*190*14*35,2 CR-MFD067U / ME521813 Ceramics SKV	300	190	14	35.2
41100-5K100	Clutch disc 300*190*14*35.2 41100-5K100 HD65/72 SKV	300	190	14	35.2
ISD136Y	Clutch disc 300*190*21*28,9 / ISD136Y/ISD136U / 8-97076-639-0 SKV	300	190	21	28.9
HND008	Clutch disc 325*210*10*38,1 / HND008 / 31250-2621/HND063U/ISD010U/ISD143 SKV	325	210	10	38.1
ISD010U	Clutch disc 325*210*10*38,1 31250-2621/HND063U/ISD010U Ceramics SKV	325	210	10	38.1
31250-E0760	Clutch disc 325*210*14*32.4 8S HND092/31250-E0760 HINO300 damping type SKV	325	210	14	32.4
ISD092	Clutch disc 8S 325*210*14*35,2/ ISD092/ MFD005/MFD068Y/ME520436 /8-97259-940-0 HINO300 Active hub SKV	325	210	14	35.2
ISD092U	Clutch disc 325*210*14*35.2 / ISD092U 6S SKV	325	210	14	35.2
MFD072U	Clutch disc 325*210*14*35.2 / MFD072U / ME517724,ME523396 Fuso CANTER 4M50 (8S) SKV	325	210	14	35.2
MFD066 Y/S/N	Clutch disc 325*210*14*37,6 / MFD066N/Y/S / ME521044 SKV	325	210	14	37.6
MFD037U	Clutch disc 350*212*14*44 / MFD037U / ME521057 SKV	350	212	14	44,0
CR-MFD037U	Clutch disc 350*212*14*44,0 CR-MFD037U / Me521057 Ceramics SKV	350	212	14	44,0
1-31240-381-0	Clutch disc 350*220*10*38,1 / ISD003Y/ISD036Y/NDD027U / 31250-2842 / 1-31240-381-0 SKV	350	220	10	38.1
HND016Y	Clutch disc 350*220*10*44,7 / HND016Y / 31250-2750 SKV	350	250	10	44.7
ISD084U	Clutch disc 350*220*10*44,7 / ISD084U / 1-31240-971-1 FSR90 SKV	350	220	10	44.7
CR-HND047U	Clutch disc 350*220*10*44,7 CR-HND047U / 31250-4990 Ceramics SKV	350	220	10	44.7
1-87610-140-0	Clutch disc 350*220*10*45 ISD193U / 1-87610-140-0 Active hub 8S SKV	350	220	10	45
31250-E0520	Clutch disc 380*220*10*44.5 HINO500 31250-E0520 HND058Y SKV	380	220	10	44,5
MFD071Y	Clutch disc 380*220*14*44 / MFD071Y / ME521606 SKV	380	220	14	44,0

Clutch discs




Article	Nomenclature	Out D, mm	In D, mm	number of teeth (t)	M D, mm
1-31240-739-0	Clutch disc 380*240*10*44,7 / ISD058U / 1-31240-739-0 / MFD099U SKV	380	240	10	44.7
NDD017	Clutch disc 380*240*12*42,0 / NDD017 / 30100-90612 SKV	380	240	12	42.0
HND009W	Clutch disc 430*250*10*50,8 / HND009W/ISD078Y/009N/065Y / 31250-3924/31250-5561 SKV	430	250	10	50.8
HND045Y	Clutch disc 430*250*10*50,8 / HND045Y/009N/065Y/ISD078Y / 31250-3924 Ceramics SKV	430	250	10	50.8
MFD016	Clutch disc 430*250*14*48,0 / MFD016 / ME550755 SKV	430	250	14	48.0
MFD058U	Clutch disc 430*250*14*48,0 / MFD058U SKV	430	250	14	48.0
ISD029Y	Clutch disc 430*250*16*45 / ISD029Y / 1-31240-240-0 SKV	430	250	16	45.0
NDD036Y	Clutch disc 430*250*18*50,0 / NDD036Y/NDD054U Ceramics SKV	430	250	18	50.0
30100-90677	Clutch disc 430*250*18*50,0 / NDD054U/NDD036Y/30100-90677 SKV	430	250	18	50.0
ISD029Y	Clutch disc 430*260*16*45,0 / ISD029Y Ceramics SKV	430	260	16	45.0

Types of clutch covers



Clutch covers




Article	Nomenclature	Out D, mm	In D, mm	C D, mm	Type
HNC 549	Clutch cover (with bearing) 430*250*456 HNC 549 PL, 31210-E0660 HINO700 E-3 SKV	430	250	456	PL
ISC 590	Clutch cover 250*160*278 ISC590 / 8-97090-843-0 DT NKR/NHR/NHS 93-98` SKV	250	160	278	DT
MFC 537	Clutch cover 260*170*298 DS MFC 529/528/MFC537 ME500066 SKV	260	170	298	DS
Me500508	Clutch cover 275*175*311 MFC 540/ ME500508 SKV	275	175	311	DT
ISC 567	Clutch cover 275*180*320 ISC 567/NSC627 DS SKV	275	180	320	DS
1-31220-147-1	Clutch cover 300*190*350 / ISC549 LS 1-31220-147-1 ISUZU FORWARD Frear12/Nrear32/Frear32/FRD12 85 SKV	300	190	350	LS
MFC 560	Clutch cover 300*190*350 / MFC560 / ME521103 SKV	300	190	350	DT
HNC 519	Clutch cover 325*210*368 HNC 519/HNC509/HNC543 / 31210-2420 SKV	325	210	368	LS
8-97351-794-0	Clutch cover 325*210*368 ISC 592/ 8-97351-794-0 SKV	325	210	368	DT
MFC 521	Clutch cover 325*210*368 MFC521 LS SKV	325	210	368	LS
HNC 525	Clutch cover 325*210*368 DT HNC525,S3121-02930,31210-37091,31210-2930 HINO300 Euro 4/3 SKV	325	210	368	DT
ME512211	Clutch cover 325*210*368 DT MFC590, ME512211 Fuso CANTER 4M50 SKV	325	210	368	DT
MFC 561	Clutch cover 350*220*375 DS MFC 561 / ME523759 SKV	350	220	375	DS
HNC 522	Clutch cover 350*220*379 LS HNC 522/HNC 540/ 31210-2270 SKV	350	220	379	LS
31210-E0240	Clutch cover 380*220*405 LS HINO500 31210-E0240 HNC541 SKV	380	220	405	LS
1-31220-372-2	Clutch cover 380*240*405 LS ISC 556 / ISC540 / 1-31220-372-2 SKV	380	220	405	LS
ISC 518-1	Clutch cover 430*250*456 ISC 518-1 LS SKV	430	250	456	LS
HNC 532	Clutch cover 430*260*456 HNC 532 / 31210-2790 / S3121-02790 SKV	430	260	456	DS


Types of clutch covers




Diaphragm strap type **DS**



Unity type **DU**




Twin plate type **TW**



Release bearings

Article	Nomenclature
1-31310-012-0	Release bearing 1-31310-012-0 Isuzu SKV
1-31310-026-0	Release bearing 1-31310-026-0/1-87610-109-0 ISUZU FSR34,FSR90, Frear/FSR/FTR/FTS 08~ SKV
31230-37050	Release bearing 31230-37050 HINO300 E4 / T-DYNA N04C SKV
8-97255-313-0	Release bearing 78TKL4801AR / 8-97255-313-0 Isuzu SKV
31242-1110	Release bearing CT5586ARSE/SF1135 31230-1030A/1050/31242-1110 HO7C/J05/08C SKV
RCT4075-1S	Release bearing RCT4075-1S/30502-21000/5-86104-535/40TRK-1/TK40-4AK TD23,25,27 VG30 SKV
TK70-1A/CT70B	Release bearing TK70-1A/CT70B TK70-9/U3 ME632049/31242-1260A/S31242-1260A/1-09820-118-0/9-00 SKV
106TKC7001	Release bearing 106TKC7001 1-09820-080-0 / 30502-90011 / 31242-1150A / ME524161 /S3124-21150 SKV
58TKA3703B	Release bearing 58TKA3703B SKV
60TMK20	Release bearing 60TMK20 (NIS) ME624278 6D14/16FK315/1625/416//516/425 SKV
30502-45P00	Release bearing 62TKC4001/30502-45P00/30502-W1701/RCT40SA3/U430 ED35,FD35,TD42,RD28 SKV
78TKC5401	Release bearing 78TKC5401/CT541SA /1-09820-078-0 Nrear/NKR/NPR/NPS/NQR 87~ SKV
78TKL4001AR	Release bearing 78TKL4001AR SKV
65TNK20	Release bearing HINO500 65TNK20 / S312421240 / 31242-1240 SKV
1304-16-510A	Release bearing RCT55B/1304-16-510A/SL SKV
TK55-1A1	Release bearing TK55-1A1 / 55TMK804/2E / CT55BL1 / 1-09820-008-0 SKV
ME523197	Hydraulic release bearing ME523197 (SD029) 4M50/4M51 FE7#C,82C,83C SKV
ME538976	Hydraulic bearing ME538976/ME539937/ME523205/ME523208/CSC2524 4M50/4M51 SKV

Brake cylinders



Article	Nomenclature	D"
58620-5K500	Brake master cylinder 58620-5K500 1-1/4 HYUNDAI COUNTY/HD45/HD65/HD72/HD78 SKV	1-1/4
58620-5L000	Brake master cylinder 58620-5L000 HYUNDAI County/HD72/78 (Euro-3) SKV	
8-97358-878-0	Brake wheel cylinder 8-97358-878-0/270 1-5/16" ISUZU LHD Rear L SKV	1-5/16
8-97358-879-0	Brake wheel cylinder 8-97358-879-0/272 1-5/16" ISUZU LHD Rear R SKV	1-5/16
8-97358-880-0	Brake wheel cylinder 8-97358-880-0/271 1-5/16" ISUZU LHD Rear L SKV	1-5/16
8-97358-881-0	Brake wheel cylinder 8-97358-881-0/273 1-5/16" ISUZU LHD Rear R SKV	1-5/16
58120-45201	Brake wheel cylinder 58120-45201 HYUNDAI COUNTY/HD45/HD65/HD72/HD78 FRONT L SKV	
58220-45201	Brake wheel cylinder 58220-45201 HYUNDAI COUNTY/HD45/HD65/HD72/HD78 FRONT R SKV	
58320-45201	Brake wheel cylinder 58320-45201 HYUNDAI COUNTY/HD45/HD65/HD72/HD78 REAR L SKV	
58420-45201	Brake wheel cylinder 58420-45201 HYUNDAI COUNTY/HD45/HD65/HD72/HD78 REAR R SKV	
8-97358-874-0	Brake wheel cylinder 8-97358-874-0/276 1-3/16" ISUZU LHD Front L without pumping SKV	1-3/16
8-97358-875-0	Brake wheel cylinder 8-97358-875-0 1-3/16" ISUZU LHD Front R without pumping SKV	1-3/16
8-97358-876-0	Brake wheel cylinder 8-97358-876-0 1-3/16" ISUZU LHD front L with pumping SKV	1-3/16
8-97358-877-0	Brake wheel cylinder 8-97358-877-0/277 1-3/16" ISUZU LHD Front R with pumping SKV	1-3/16
58130-62003	Brake wheel cylinder 58130-62003 HYUNDAI HD120 front LH SKV	
58150-62003	Brake wheel cylinder 58150-62003 HYUNDAI HD120 front LH SKV	
58230-62004	Brake wheel cylinder 58230-62003/ 62004 HYUNDAI HD120 front RH SKV	
58250-62003	Brake wheel cylinder 58250-62003 HYUNDAI HD120 front RH SKV	
58330-62004	Brake wheel cylinder 58330-62004 HYUNDAI HD120 rear LH SKV	
58350-62004	Brake wheel cylinder 58350-62004 HYUNDAI HD120 rear LH SKV	
58430-62004	Brake wheel cylinder 58430-62004 HYUNDAI HD120 rear RH SKV	
58450-62004	Brake wheel cylinder 58450-62004/52450-62010 HYUNDAI HD120 rear RH SKV	

FOR NOTES



Ganjiang Road,
Economic And Technological Development Zone,
Jiaozhou, Qingdao, Shandong Province, China
SKV Technology Co.,Ltd.

☎ +852-8191-4065 ✉ sales@truckskv.com
🌐 www.truckskv.com